

Uptimax Ni-Cd batteries

Type UP1 L and UP1 M Installation and operating instructions

Important recommendations

- Never allow an exposed flame or spark near the batteries, particularly while charging.
- Never smoke while performing any operation on the battery.
- For protection, wear rubber gloves, long sleeves, and appropriate splash goggles or face shield.
- The electrolyte is harmful to skin and eyes. In the event of contact with skin or eyes, wash immediately with plenty of water. If eyes are affected, flush with water, and obtain immediate medical attention.
- Remove all rings, watches and other items with metal parts before working on the battery.
- Use insulated tools.
- Avoid static electricity and take measures for protection against electric shocks.
- Discharge any possible static electricity from clothing and/or tools by touching an earth-connected part "ground" before working on the battery.

1. Receiving the shipment

Unpack the battery immediately upon arrival. Do not overturn the package. Check the packages and cells for transport damage.

The battery is shipped filled and charged, and is ready for immediate use.

Transport seals are located under the lid of each vent and they must be removed prior to charging.

The battery must never be charged with the plastic transport seals in place as this is dangerous and can cause permanent damage.

2. Storage

Store the battery indoors in a dry, clean, cool location (0°C to +30°C / +32°F to +86°F) and well ventilated space on open shelves.

Storage of a filled battery at temperatures above +30°C (+86°F) can result in loss of capacity. This can be as much as 5% per 10°C (18°F) above +30°C (+86°F) per year.

Do not store in direct sunlight or expose to excessive heat.

Uptimax batteries are supplied filled with electrolyte and charged, **they can be stored in this condition for maximum 24 months.**

Never drain the electrolyte from the cells.

- When deliveries are made in cardboard boxes, store without opening the boxes.
- When deliveries are made in plywood boxes, open the boxes before the storage. The lid and the packing material on top of the cells must be removed.

3. Installation

3.1. Location

Install the battery in a dry and clean room. Avoid direct sunlight and heat. The battery will give the best performance and maximum service life when the ambient temperature is between +10°C to +30°C (+50°F to +86°F).

3.2. Ventilation

During the last part of charging, the battery is emitting gases (oxygen and hydrogen mixture). At normal float charge the gas evolution is very small but some ventilation is necessary.

Note that special regulations for ventilation may be valid in your area depending on the application.

3.3. Mounting

Verify that cells are correctly interconnected with the appropriate polarity. The battery connection to load should be with nickel plated cable lugs. Apply a thin layer of anti-corrosion oil to protect the connectors and terminals from corrosion.

Recommended torques for terminal bolts are:

- M 6 = 11 ± 1.1 N.m
- M 8 = 20 ± 2 N.m
- M 10 = 30 ± 3 N.m

The connectors and terminal should be corrosion-protected by coating with a thin layer of anti-corrosion oil.

Remove the transport seals and close the vent plugs.

3.4. Electrolyte

When checking the electrolyte levels, a fluctuation in level between cells is not abnormal and is due to the different amounts of gas held in the separators of each cell. The level should be not less than 5 mm below the maximum level mark and there is normally no need to adjust it.

In case of spillage of electrolyte during the transport, the cells have to be topped up with E22 electrolyte.

Do not top-up prior to initial charge.



4. Commissioning

Verify that the ventilation is adequate during this operation.

Charge at constant current is preferable.

■ Cells stored up to 6 months:

A commissioning charge is normally not required and the cells are ready for immediate use.

■ Cells stored more than 6 months and up to 2 years:

A commissioning charge is necessary:

• Constant current charge:

16 h at 0.1 C₅ A recommended (see Table A).

Notice: At the end of charge, the cell voltage will reach about 1.85 V, thus the charger shall be able to supply such a voltage.

When the charger maximum voltage setting is too low to supply constant current charging, divide the battery into two parts to be charged individually at constant current.

• Constant potential charge:

1.65 V/cell for a minimum of 30 h with current limited to 0.1 C₅ A (see the current in Table A).

If these methods are not available, then charging may be carried out at lower voltages, 1.50 V/cell for 72 hours minimum.

Note: When full battery performance is required for capacity test purposes, the battery has to be charged in accordance with IEC62259 section 7 (7.1 & 7.2).

5. Charging in service

The recommended charging voltages for continuous parallel operation, with occasional battery discharges, are:

■ Two level charge:

- float level: 1.43 ± 0.01 V/cell
- high rate (boost) level: 1.45 ± 0.01 V/cell

■ Single level charge:

1.43 ± 0.01 V/cell

Uptimax Ni-Cd batteries

6. Periodic Maintenance

Uptimax is a low maintenance battery and requires the minimum of maintenance.

As a periodic maintenance, the following is recommended:

- Check the charging voltage. In parallel operation, it is of great importance that the recommended charging voltage remains unchanged. The charging voltage should be checked at least once yearly. High water consumption of the battery is usually caused by improper voltage setting of the charger.

- Keep the battery clean using only water. Do not use a wire brush or solvents of any kind.

- Check visually the electrolyte level.

Never let the level fall below the minimum level mark. Use only distilled or de-ionized water to top-up.

Topping up of the Uptimax battery **shall be carried out when battery is fully charged.**

Experience will tell the time interval between topping-up.

Note: *There is no need to check the electrolyte density periodically. Interpretation of density measurements is difficult and could be misleading.*

7. Environment

To protect the environment all used batteries must be recycled. Contact your local Saft representative for further information.

Table A:

Cell type	Capacity C ₅ Ah (Ah)	Charging current 0.1 C ₅ A (A)	Cell connection bolt per pole	Cell type	Capacity C ₅ Ah (Ah)	Charging current 0.1 C ₅ A (A)	Cell connection bolt per pole
UP1 L 15	15	1.5	M 6	UP1 M 8	8	0.8	M 6
UP1 L 30	30	3.0	M 6	UP1 M 16	16	1.6	M 6
UP1 L 47	47	4.7	M 6	UP1 M 24	24	2.4	M 6
UP1 L 62	62	6.2	M 6	UP1 M 32	32	3.2	M 6
UP1 L 75	75	7.5	2 x M 6	UP1 M 40	40	4.0	M 6
UP1 L 95	95	9.5	M 8	UP1 M 48	48	4.8	M 6
UP1 L 110	110	11.0	2 x M 6	UP1 M 65	65	6.5	2 x M 6
UP1 L 140	140	14.0	M 10	UP1 M 75	75	7.5	M 8
UP1 L 185	185	18.5	M 10	UP1 M 100	100	10.0	M 10
UP1 L 235	235	23.5	M 10	UP1 M 125	125	12.5	M 10
UP1 L 280	280	28.0	M 10	UP1 M 150	150	15.0	M 10
UP1 L 325	325	32.5	2 x M 10	UP1 M 170	170	17.0	M 10
UP1 L 375	375	37.5	2 x M 10	UP1 M 195	195	19.5	M 10
UP1 L 420	420	42.0	2 x M 10	UP1 M 220	220	22.0	M 10
UP1 L 470	470	47.0	2 x M 10	UP1 M 245	245	24.5	2 x M 10
UP1 L 515	515	51.5	2 x M 10	UP1 M 270	270	27.0	2 x M 10
UP1 L 560	560	56.0	2 x M 10	UP1 M 295	295	29.5	2 x M 10
UP1 L 610	610	61.0	3 x M 10	UP1 M 320	320	32.0	2 x M 10
UP1 L 650	650	65.0	3 x M 10	UP1 M 345	345	34.5	2 x M 10
UP1 L 700	700	70.0	3 x M 10	UP1 M 370	370	37.0	2 x M 10
UP1 L 750	750	75.0	3 x M 10	UP1 M 395	395	39.5	2 x M 10
UP1 L 800	800	80.0	3 x M 10	UP1 M 420	420	42.0	2 x M 10
UP1 L 840	840	84.0	3 x M 10	UP1 M 445	445	44.5	2 x M 10
UP1 L 890	890	89.0	4 x M 10	UP1 M 490	490	49.0	3 x M 10
UP1 L 940	940	94.0	4 x M 10	UP1 M 540	540	54.0	3 x M 10
UP1 L 980	980	98.0	4 x M 10	UP1 M 590	590	59.0	3 x M 10
UP1 L 1030	1030	103	4 x M 10	UP1 M 640	640	64.0	3 x M 10
UP1 L 1120	1120	112	4 x M 10	UP1 M 690	690	69.0	4 x M 10
UP1 L 1220	1220	122	5 x M 10	UP1 M 740	740	74.0	4 x M 10
UP1 L 1300	1300	130	5 x M 10	UP1 M 785	785	78.5	4 x M 10
UP1 L 1400	1400	140	5 x M 10	UP1 M 835	835	83.5	4 x M 10
UP1 L 1500	1500	150	6 x M 10	UP1 M 885	885	88.5	4 x M 10
UP1 L 1600	1600	160	6 x M 10	UP1 M 935	935	93.5	5 x M 10
UP1 L 1700	1700	170	6 x M 10	UP1 M 985	985	98.5	5 x M 10
UP1 M 1030	1030	103	5 x M 10	UP1 M 1130	1130	113	6 x M 10
UP1 M 1130	1130	113	6 x M 10	UP1 M 1230	1230	123	6 x M 10
UP1 M 1230	1230	123	6 x M 10	UP1 M 1330	1330	133	6 x M 10
UP1 M 1330	1330	133	6 x M 10				

Saft
Industrial Battery Group

12, rue Sadi Carnot
93170 Bagnole - France
Tel: +33 1 49 93 19 18
Fax: +33 1 49 93 19 64

www.saftbatteries.com

Doc N° 21574-2-0408

Data in this document is subject to change without notice and becomes contractual only after written confirmation.

Société anonyme au capital de 31 944 000 €
RCS Bobigny B 383 703 B73

Pragma - Printed in France - 3k



SAFT